



## **Avaya Solution & Interoperability Test Lab**

---

# **Application Notes for Avtec Scout VoIP Console with Avaya Aura® Communication Manager and Avaya Aura® Session Manager – Issue 1.0**

### **Abstract**

These Application Notes describe the configuration steps required to integrate Avtec Scout VoIP Console with Avaya Aura® Communication Manager and Avaya Aura® Session Manager. Avtec Scout VoIP Console is a SIP-based system that supports inbound and outbound calls, hold, resume, mute, and transfer, and integrates with Avaya Aura® Session Manager via a SIP trunk.

Readers should pay attention to **Section 2**, in particular the scope of testing as outlined in **Section 2.1** as well as the observations noted in **Section 2.2**, to ensure that their own use cases are adequately covered by this scope and results.

Information in these Application Notes has been obtained through DevConnect compliance testing and additional technical discussions. Testing was conducted via the DevConnect Program at the Avaya Solution and Interoperability Test Lab.

# 1 Introduction

These Application Notes describe the configuration steps required to integrate Avtec Scout VoIP Console with Avaya Aura® Communication Manager and Avaya Aura® Session Manager. Avtec Scout VoIP Console is a SIP-based system that supports inbound and outbound calls, hold, resume, mute, and transfer, and integrates with Avaya Aura® Session Manager via a SIP trunk.

## 2 General Test Approach and Test Results

The interoperability compliance test included feature and serviceability testing. The feature testing focused on establishing calls between Avtec Scout VoIP Console, Avaya SIP and H.323 IP Deskphones, and the PSTN, and exercising basic telephony features, such as hold, mute, and transfer.

The serviceability testing focused on verifying that Avtec Scout VoIP Console came back into service after re-connecting the Ethernet cable and rebooting the system. The following sub-section covers the features and functionality that were covered in more detail.

DevConnect Compliance Testing is conducted jointly by Avaya and DevConnect members. The jointly-defined test plan focuses on exercising APIs and/or standards-based interfaces pertinent to the interoperability of the tested products and their functionalities. DevConnect Compliance Testing is not intended to substitute full product performance or feature testing performed by DevConnect members, nor is it to be construed as an endorsement by Avaya of the suitability or completeness of a DevConnect member's solution.

Avaya recommends our customers implement Avaya solutions using appropriate security and encryption capabilities enabled by our products. The testing referenced in this DevConnect Application Note included the enablement of supported encryption capabilities in the Avaya products. Readers should consult the appropriate Avaya product documentation for further information regarding security and encryption capabilities supported by those Avaya products.

Support for these security and encryption capabilities in any non-Avaya solution component is the responsibility of each individual vendor. Readers should consult the appropriate vendor-supplied product documentation for more information regarding those products.

For the testing associated with this Application Note, the interface between Avaya systems and Avtec Scout VoIP Console did not include use of any specific encryption features as requested by Avtec.

## 2.1 Interoperability Compliance Testing

Interoperability compliance testing covered the following features and functionality:

- Establishing a SIP trunk between Scout VoIP Console and Session Manager. This includes verifying that Scout VoIP Console successfully responds to SIP OPTIONS messages.
- Calls between Scout VoIP Console and Avaya SIP/H.323 IP Deskphones with Direct IP Media (Shuffling) enabled and disabled.
- Calls between Scout VoIP Console and the PSTN.
- G.711, G.729, and G.726 codec support.
- Proper recognition of DTMF tones from Scout VoIP Console.
- Basic telephony features, including hold, mute, redial, multiple calls, and blind/attended transfers.
- Four SIP lines registered to the Avtec Scout SIP Proxy.
- Multiple simultaneous calls to the four SIP lines and long duration calls.
- Proper system recovery after a reboot of Scout VoIP Console and loss of IP connectivity.

## 2.2 Test Results

All test cases passed with the following observations.

- Incoming call notification not heard through headset by design, external speakers are required. However, visual indication of incoming calls is provided by the Scout VoIP Console.
- Scout VoIP Console does not currently support conferencing.
- SIP TLS transport and SRTP is currently not supported by Scout VoIP Console.

## 2.3 Support


Avtec Technical Support for Scout VoIP Console can be obtained via phone, email, or website.

- **Phone:** 1 (800) 545-3034  
1 (803) 358-3601
- **Email:** [customersupport@avtecinc.com](mailto:customersupport@avtecinc.com)
- **Web:** <https://www.avtecinc.com/support>

### 3 Reference Configuration

**Figure 1** illustrates a sample configuration with an Avaya SIP-based network that includes the following products:

- Communication Manager running with a G450 Media Gateway and Avaya Aura® Media Server providing media resources.
- Session Manager connected to Communication Manager via a SIP trunk.
- Avaya Aura® System Manager to configure Session Manager.
- Avaya H.323 and SIP Deskphones.
- Scout VoIP Console connected to Session Manager via a SIP trunk.
- Scout VoIP Console was installed on a desktop PC running Microsoft Windows 10 and included the following components: Scout VPGate, Scout SIP Proxy, and Scout Manager. Scout Manager was used to configure the Scout VoIP Console.



**Figure 1: Avaya SIP Telephony Network with Avtec Scout VoIP Console**

## 4 Equipment and Software Validated

The following equipment and software were used for the sample configuration provided:

Equipment/Software	Release/Version
Avaya Aura® Communication Manager	8.1.0.1.0-SP1 (R018x.01.0.890.0 with Patch 25393)
Avaya G450 Media Gateway	FW 40.25.0
Avaya Aura® Media Server	v.8.0.1.121
Avaya Aura® System Manager	8.1.0.0 Build No. – 8.1.0.0.733078 Software Update Revision No: 8.1.0.0.079814
Avaya Aura® Session Manager	8.1.0.0.810007
Avaya 96x1 Series IP Deskphones	6.8003 (H.323) 7.1.5.0.11 (SIP)
Avaya J129 SIP Deskphone	4.0.2.0.8
Avtec Scout VoIP Console running on Microsoft Windows 10, including the following components: <ul style="list-style-type: none"><li>Scout Console</li><li>Scout VPGate</li><li>Scout SIP Proxy</li><li>Scout Manager</li></ul>	4.10.0.57 4.10.0.267 4.10.0.39 4.10.0.57

## 5 Configure Avaya Aura® Communication Manager

This section describes the steps for configuring a SIP trunk to Session Manager and routing calls to Scout. Administration of Communication Manager was performed using the System Access Terminal (SAT).

This section covers the following configuration:

- **IP Node Names** to associate names with IP addresses.
- **IP Codec Set** to specify the codec type used for calls to Scout VoIP Console.
- **IP Network Region** to specify the domain name and the IP codec set, to enable IP-IP direct audio (i.e., Shuffling), and to specify the UDP port range.
- **SIP trunk** for calls towards Session Manager and Scout.
- **Private Numbering** to allow the caller's extension to be sent to Scout VoIP Console.
- **Call Routing** to route calls to Scout VoIP Console using AAR.

### 5.1 Administer IP Node Names

In the **IP Node Names** form, assign an IP address and host name for Communication Manager (*procr*) and Session Manager (*devcon-sm*). The host names will be used in other configuration screens of Communication Manager.

change node-names ip		Page 1 of 2
		IP NODE NAMES
Name	IP Address	
default	0.0.0.0	
devcon-aes	10.64.102.119	
devcon-ams	10.64.102.118	
<b>devcon-sm</b>	<b>10.64.102.117</b>	
<b>procr</b>	<b>10.64.102.115</b>	
procr6	::	
( 6 of 6 administered node-names were displayed )		
Use 'list node-names' command to see all the administered node-names		
Use 'change node-names ip xxx' to change a node-name 'xxx' or add a node-name		

## 5.2 Administer IP Codec Set

In the **IP Codec Set** form, select the audio codec type supported for calls routed over the SIP trunk to Scout VoIP Console. The form is accessed via the **change ip-codec-set 1** command. Note the codec set number since it will be used in the IP Network Region covered in the next section. For the compliance test, G.711MU, G.729, and G.726 codecs were used.

change ip-codec-set 1

Page 1 of 2

IP MEDIA PARAMETERS

Codec Set: 1

Audio Codec	Silence Suppression	Frames Per Pkt	Packet Size (ms)
1: G.711MU	n	2	20
2: G.729	n	2	20
3: G.726A-32K	n	2	20
4:			
5:			
6:			
7:			

Media Encryption

Encrypted SRTCP: best-effort

1: 1-srtp-aescm128-hmac80

2: none

3:

4:

5:

### 5.3 Administer IP Network Region

In the **IP Network Region** form, the **Authoritative Domain** field is configured to match the domain name configured on Session Manager. In this configuration, the domain name is *avaya.com*. By default, **IP-IP Direct Audio** (shuffling) is enabled to allow audio traffic to be sent directly between Scout VoIP Console and IP endpoints without using media resources in the Avaya G450 Media Gateway or Avaya Media Server. The **IP Network Region** form also specifies the **IP Codec Set** to be used for calls routed over the SIP trunk to Session Manager. This codec set is used when its corresponding network region (i.e., IP Network Region 1) is specified in the SIP signaling group.

change ip-network-region 1		Page 1 of 20
IP NETWORK REGION		
Region: 1		
Location: 1	<b>Authoritative Domain: avaya.com</b>	
Name:	Stub Network Region: n	
MEDIA PARAMETERS		<b>Intra-region IP-IP Direct Audio: yes</b>
Codec Set: 1	<b>Inter-region IP-IP Direct Audio: yes</b>	
UDP Port Min: 2048	IP Audio Hairpinning? n	
UDP Port Max: 50999		
DIFFSERV/TOS PARAMETERS		
Call Control PHB Value: 46		
Audio PHB Value: 46		
Video PHB Value: 26		
802.1P/Q PARAMETERS		
Call Control 802.1p Priority: 6		
Audio 802.1p Priority: 6		
Video 802.1p Priority: 5		
H.323 IP ENDPOINTS		AUDIO RESOURCE RESERVATION PARAMETERS
H.323 Link Bounce Recovery? y	RSVP Enabled? n	
Idle Traffic Interval (sec): 20		
Keep-Alive Interval (sec): 5		
Keep-Alive Count: 5		



## 5.4 Administer SIP Trunk to Session Manager

Prior to configuring a SIP trunk group for communication with Session Manager, a SIP signaling group must be configured. Configure the **Signaling Group** form as follows:

- Set the **Group Type** field to *sip*.
- Set the **IMS Enabled** field to *n*.
- The **Transport Method** field was set to *tls*.
- Specify the Ethernet processor (*procr*) of Communication Manager and Session Manager as the two ends of the signaling group in the **Near-end Node Name** field and the **Far-end Node Name** field, respectively. These field values are taken from the **IP Node Names** form in **Section 5.1**.
- Set the TLS port value (e.g., *5061*) in the **Near-end Listen Port** and the **Far-end Listen Port** fields.
- The preferred codec for the call will be selected from the IP codec set assigned to the IP network region specified in the **Far-end Network Region** field.
- Enter the domain name of Session Manager in the **Far-end Domain** field. In this configuration, the domain name is *avaya.com*.
- The **Direct IP-IP Audio Connections** field was enabled on this form.
- The **DTMF over IP** field should be set to the default value of *rtp-payload*.

Communication Manager supports DTMF transmission using RFC 2833. The default values for the other fields may be used.

add signaling-group 10		Page 1 of 2
SIGNALING GROUP		
Group Number: 10	Group Type: sip	
IMS Enabled? n	Transport Method: tls	
Q-SIP? n		
IP Video? n	Enforce SIPS URI for SRTP? n	
Peer Detection Enabled? y	Peer Server: SM	Clustered? n
Prepend '+' to Outgoing Calling/Alerting/Diverting/Connected Public Numbers? y		
Remove '+' from Incoming Called/Calling/Alerting/Diverting/Connected Numbers? n		
Alert Incoming SIP Crisis Calls? n		
Near-end Node Name: procr	Far-end Node Name: devcon-sm	
Near-end Listen Port: 5061	Far-end Listen Port: 5061	
	Far-end Network Region: 1	
Far-end Domain: avaya.com		
Incoming Dialog Loopbacks: eliminate	Bypass If IP Threshold Exceeded? n	
	RFC 3389 Comfort Noise? n	
DTMF over IP: rtp-payload	Direct IP-IP Audio Connections? y	
Session Establishment Timer(min): 3	IP Audio Hairpinning? n	
Enable Layer 3 Test? y	Initial IP-IP Direct Media? n	
H.323 Station Outgoing Direct Media? n	Alternate Route Timer(sec): 6	

Configure the **Trunk Group** form as shown below. This trunk group is used for SIP calls to Scout VoIP Console. Set the **Group Type** field to *sip*, set the **Service Type** field to *tie*, specify the signaling group associated with this trunk group in the **Signaling Group** field, and specify

the **Number of Members** supported by this SIP trunk group. Accept the default values for the remaining fields.

add trunk-group 10		Page 1 of 5	
TRUNK GROUP			
Group Number: 10	<b>Group Type: sip</b>	CDR Reports: y	
Group Name: To devcon-sm	COR: 1	TN: 1	TAC: 1010
Direction: two-way	Outgoing Display? n		
Dial Access? n	Night Service:		
Queue Length: 0			
<b>Service Type: tie</b>	Auth Code? n		
	Member Assignment Method: auto		
	<b>Signaling Group: 10</b>		
	<b>Number of Members: 10</b>		

On **Page 3** of the trunk group form, set the **Numbering Format** field to *private*. This field specifies the format of the calling party number sent to the far-end.

add trunk-group 10		Page 3 of 21	
TRUNK FEATURES			
ACA Assignment? n	Measured: none	Maintenance Tests? y	
Suppress # Outpulsing? n	<b>Numbering Format: private</b>	UI Treatment: service-provider	
	Replace Restricted Numbers? n	Replace Unavailable Numbers? n	
	Hold/Unhold Notifications? y	Modify Tandem Calling Number: no	
Show ANSWERED BY on Display? y			

On **Page 4** of the trunk group form, the default settings were used as shown below.

add trunk-group 10		Page 4 of 21	
PROTOCOL VARIATIONS			
Mark Users as Phone? n			
Prepend '+' to Calling/Alerting/Diverting/Connected Number? n			
Send Transferring Party Information? n			
Network Call Redirection? n			
Send Diversion Header? n			
Support Request History? y			
Telephone Event Payload Type:			
Convert 180 to 183 for Early Media? n			
Always Use re-INVITE for Display Updates? n			
Identity for Calling Party Display: P-Asserted-Identity			
Block Sending Calling Party Location in INVITE? n			
Accept Redirect to Blank User Destination? n			
Enable Q-SIP? n			
Interworking of ISDN Clearing with In-Band Tones: keep-channel-active			
Request URI Contents: may-have-extra-digits			

## 5.5 Configure Private Numbering

Configure the **Numbering – Private Format** form to send the calling party number to the far-end. Add an entry so that local stations with a 5-digit extension beginning with ‘7’ whose calls are routed over any trunk group, including SIP trunk group 10, have the extension sent to Scout VoIP Console.

change private-numbering 0					Page 1 of 2
NUMBERING - PRIVATE FORMAT					
Ext Len	Ext Code	Trk Grp(s)	Private Prefix	Total Len	
5	7			5	Total Administered: 1 Maximum Entries: 540

## 5.6 AAR Call Routing

Configure the uniform dial plan table to route calls using AAR for dialed digits that are 5-digits long and begin with ‘78’. This would cover call routing to the Scout VoIP Console extensions (i.e., 78800 – 78803). For the compliance test, four Scout VoIP Console lines were configured as shown in **Section 7.3**.

change uniform-dialplan 7					Page 1 of 2
UNIFORM DIAL PLAN TABLE					
Percent Full: 0					
Matching Pattern	Len	Del	Insert Digits	Net Conv	Node Num
78	5	0		aar	n

SIP calls to Session Manager are routed over a SIP trunk via AAR call routing. Configure the AAR analysis form and add an entry that routes digits beginning with “78” to route pattern 10 as shown below. Note that the **Call Type** was set to *lev0*. This routes calls to SIP stations and to Scout VoIP Console.

change aar analysis 7							Page 1 of 2
AAR DIGIT ANALYSIS TABLE							
Location: all							
Percent Full: 2							
	Dialed String	Total Min	Total Max	Route Pattern	Call Type	Node Num	ANI Req'd
7		7	7	254	aar		n
<b>78</b>		<b>5</b>	<b>5</b>	<b>10</b>	<b>lev0</b>		<b>n</b>
8		7	7	254	aar		n
9		7	7	254	aar		n
							n
							n

Configure a preference in **Route Pattern 10** to route calls over SIP trunk group 10 as shown below.

change route-pattern 10										Page 1 of 3	
Pattern Number: 10										Pattern Name: To devcon-sm	
SCCAN? n      Secure SIP? n      Used for SIP stations? n											
Grp FRL NPA Pfx Hop Toll No.      Inserted										DCS/ IXC	
No                      Mrk Lmt List Del Digits										QSIG	
Dgts										Intw	
1:	10	0								n	user
2:										n	user
3:										n	user
4:										n	user
5:										n	user
6:										n	user
BCC VALUE		TSC	CA-TSC		ITC BCIE		Service/Feature	PARM Sub	Numbering	LAR	
0 1 2 M 4 W			Request					Dgts	Format		
1:	y	y	y	y	y	n	n	rest	unk-unk	none	
2:	y	y	y	y	y	n	n	rest		none	
3:	y	y	y	y	y	n	n	rest		none	
4:	y	y	y	y	y	n	n	rest		none	
5:	y	y	y	y	y	n	n	rest		none	
6:	y	y	y	y	y	n	n	rest		none	

## 6 Configure Avaya Aura® Session Manager

This section provides the procedures for configuring Session Manager. The procedures include adding the following items:

- Adaptation
- SIP Entity for Scout VoIP Console
- Entity Link, which defines the SIP trunk parameters used by Session Manager when routing calls to/from Scout VoIP Console
- Routing Policies and Dial Patterns
- Session Manager, corresponding to the Avaya Aura® Session Manager Server to be managed by Avaya Aura® System Manager

Configuration is accomplished by accessing the browser-based GUI of Avaya Aura® System Manager using the URL “https://<ip-address>/SMGR”, where <ip-address> is the IP address of Avaya Aura® System Manager. Log in with the appropriate credentials.

**Note:** It is assumed that basic configuration of Session Manager has already been performed. *This section will focus on the configuration of the adaptation, SIP entity, entity link, and call routing for Avtec Scout VoIP Console only.*

## 6.1 Add Adaptation

Session Manager can be configured with Adaptations that can modify SIP messages before or after routing decisions have been made; for example, replacing a domain name with an IP address as shown in this section. To create an **Adaptation** that will be applied to the Scout VoIP Console SIP entity in **Section 6.2**, navigate to **Elements → Routing → Adaptations** and click on the **New** button (not shown). In the **General** section, enter the following values. Use default values for all remaining fields.

- **Adaptation Name:** Enter a descriptive name for the Adaptation (e.g., *Avtec Adaptation*).
- **Module Name:** Select **DigitConversionAdapter**.
- **Module Parameter Type:** Select **Single Parameter**.
- **Module Parameter:** Enter the Scout VoIP Console IP address.

The screenshot shows the Avaya Aura System Manager 8.1 interface. The top navigation bar includes the Avaya logo, 'Aura® System Manager 8.1', and tabs for Users, Elements, Services, Widgets, and Shortcuts. A search bar and a user profile 'admin' are also present. The left sidebar shows a tree view with 'Routing' selected, and 'Adaptations' highlighted. The main content area is titled 'Adaptation Details' and contains a 'General' section with the following fields:

- \* Adaptation Name:** Text input field containing 'Avtec Adaptation'.
- \* Module Name:** Dropdown menu with 'DigitConversionAdapter' selected.
- Module Parameter Type:** Dropdown menu with 'Single Parameter' selected.
- Module Parameter :** Text input field containing '192.168.100.251'.
- Egress URI Parameters:** Text input field.
- Notes:** Text input field.

Buttons for 'Commit' and 'Cancel' are located at the top right of the form area, along with a 'Help ?' link.

## 6.2 Add SIP Entity for Avtec Scout VoIP Console

In the sample configuration, one SIP trunk was configured for Scout VoIP Console, which provided four lines with four different extensions for this compliance test. These SIP extensions registered with the internal Scout VoIP Console SIP registrar/proxy, not with Session Manager.

A SIP Entity must be added for Scout VoIP Console. This SIP entity will have an adaptation rule to convert the domain name in the SIP URI of INVITE message to the Scout VoIP Console IP address and vice versa. To add a SIP Entity, select **SIP Entities** on the left and click on the **New** button on the right (not shown). The following screen is displayed. Fill in the following:

Under *General*:

- **Name:** A descriptive name.
- **FQDN or IP Address:** IP address of the Scout VoIP Console.
- **Type:** Select *SIP trunk*.
- **Adaptation:** Specify the adaptation configured in **Section 6.1**.
- **Location:** Select the location defined previously (not shown).
- **Time Zone:** Time zone for this location.

Defaults can be used for the remaining fields. Click **Commit** to save each SIP Entity definition.

The screenshot displays the Avaya Aura System Manager 8.1 interface. The top navigation bar includes the Avaya logo, user name 'admin', and search bar. The left sidebar shows the navigation menu with 'SIP Entities' selected. The main content area is titled 'SIP Entity Details' and is divided into three sections: General, Loop Detection, and Monitoring. The General section includes fields for Name, FQDN or IP Address, Type, Notes, Adaptation, Location, Time Zone, SIP Timer B/F, Minimum TLS Version, Credential name, Securable, and Call Detail Recording. The Loop Detection section includes Loop Detection Mode, Loop Count Threshold, and Loop Detection Interval. The Monitoring section includes SIP Link Monitoring and CRLF Keep Alive Monitoring. The bottom of the page shows the 'Commit' and 'Cancel' buttons.

## 6.3 Add Entity Link for Avtec Scout VoIP Console

This section covers the configuration of an Entity Link for Scout VoIP Console. This entity link will specify that SIP entity configured in **Section 6.2**.

The SIP trunk from Session Manager to Scout VoIP Console is described by an Entity link. To add an Entity Link, select **Entity Links** on the left and click on the **New** button (not shown) on the right. Fill in the following fields in the new row that is displayed:

- **Name:** A descriptive name (e.g., *Avtec Scout Link*).
- **SIP Entity 1:** Select Session Manager.
- **Protocol:** Select the appropriate protocol (e.g., *UDP*).
- **Port:** Port number to which the other system sends SIP requests.
- **SIP Entity 2:** Select the Scout SIP entity configure in **Section 6.2**.
- **Port:** Port number on which the other system receives SIP requests.
- **Connection Policy:** Select *Trusted*. *Note: If Trusted is not selected, calls from the associated SIP Entity specified in Section 6.2 will be denied.*

Click **Commit** to save the Entity Link definition.

The screenshot shows the Avaya Aura System Manager 8.1 interface. The left sidebar contains a navigation menu with the following items: Home, Routing, Domains, Locations, Conditions, Adaptations, SIP Entities, Entity Links (selected), and Time Ranges. The main content area is titled 'Entity Links' and features a table with one item. The table has columns for Name, SIP Entity 1, Protocol, Port, SIP Entity 2, and Port. The item 'Avtec Scout Link' is listed with SIP Entity 1 as 'devcon-sm', Protocol as 'UDP', and Port as '5060'. The SIP Entity 2 is 'Avtec Scout' and its Port is '5060'. The table includes a 'Filter: Enable' dropdown and a 'Select: All, None' dropdown. The 'Commit' and 'Cancel' buttons are located at the top right and bottom right of the table area.

	Name	SIP Entity 1	Protocol	Port	SIP Entity 2	Port
<input type="checkbox"/>	* Avtec Scout Link	* devcon-sm	UDP	* 5060	* Avtec Scout	* 5060



## 6.4 Add Routing Policies

Routing policies describe the conditions under which calls will be routed to the Scout VoIP Console SIP Entity specified in **Section 6.2**. To add a routing policy, select **Routing Policies** on the left and click on the **New** button (not shown) on the right. The following screen is displayed. Fill in the following:

Under *General*:

Enter a descriptive name in **Name**.

Under *SIP Entity as Destination*:

Click **Select** and then select the appropriate SIP entity to which this routing policy applies. In this case, the Scout VoIP Console SIP entity is selected.

Defaults can be used for the remaining fields. Click **Commit** to save the Routing Policy definition. The following screen shows the Routing Policy for Scout VoIP Console.

The screenshot displays the Avaya Aura System Manager 8.1 interface. The top navigation bar includes the Avaya logo, 'Aura® System Manager 8.1', and various menu items: Users, Elements, Services, Widgets, and Shortcuts. A search bar and a user profile 'admin' are also present. The left sidebar shows a tree view with 'Routing' selected, which includes sub-items like Domains, Locations, Conditions, Adaptations, SIP Entities, Entity Links, Time Ranges, Routing Policies (highlighted), Dial Patterns, Regular Expressions, and Defaults. The main content area is titled 'Routing Policy Details' and contains three sections: 'General', 'SIP Entity as Destination', and 'Time of Day'. The 'General' section has fields for 'Name' (Avtec Scout Policy), 'Disabled' (checkbox), 'Retries' (0), and 'Notes'. The 'SIP Entity as Destination' section has a 'Select' button and a table with one entry: 'Avtec Scout' with FQDN or IP Address '192.168.100.251' and Type 'SIP Trunk'. The 'Time of Day' section has buttons for 'Add', 'Remove', and 'View Gaps/Overlaps', and a table with one item showing a '24/7' time range from 00:00 to 23:59.

Name	FQDN or IP Address	Type	Notes
Avtec Scout	192.168.100.251	SIP Trunk	

Ranking	Name	Mon	Tue	Wed	Thu	Fri	Sat	Sun	Start Time	End Time	Notes
0	24/7	☑	☑	☑	☑	☑	☑	☑	00:00	23:59	Time Range 24/7

## 6.5 Add Dial Patterns

Dial patterns must be defined to direct calls to the appropriate SIP Entity. In the sample configuration, a 5-digit number beginning with '788' will be routed to lines on Scout VoIP Console.

To add a dial pattern, select **Dial Patterns** on the left and click on the **New** button (not shown) on the right. Fill in the following:

Under *General*:

- **Pattern:** Dialed number or prefix.
- **Min** Minimum length of dialed number.
- **Max** Maximum length of dialed number.
- **SIP Domain** SIP domain of dial pattern.
- **Notes** Comment on purpose of dial pattern (optional).

Under *Originating Locations and Routing Policies*:

Click **Add** and then select the appropriate location and routing policy from the list. In this case, the Scout VoIP Console routing policy is selected.

Default values can be used for the remaining fields. Click **Commit** to save this dial pattern. The following screen shows the dial pattern definitions for extensions on Scout VoIP Console.

**AVAYA** Aura® System Manager 8.1

Users ▾ Elements ▾ Services ▾ Widgets ▾ Shortcuts ▾ Search 🔍 admin

Home Routing

**Dial Pattern Details** [Help ?](#) [Commit](#) [Cancel](#)

**General**

\* **Pattern:** 788

\* **Min:** 5

\* **Max:** 5

**Emergency Call:** ☐

**SIP Domain:** -ALL- ▾

**Notes:** Avtec Scout

**Originating Locations and Routing Policies**

[Add](#) [Remove](#) [Filter: Enable](#)

1 Item

<input type="checkbox"/>	Originating Location Name ▴	Originating Location Notes	Routing Policy Name	Rank	Routing Policy Disabled	Routing Policy Destination	Routing Policy Notes
<input type="checkbox"/>	Thornton		Avtec Scout Policy	0	<input type="checkbox"/>	Avtec Scout	

Select : All, None

**Denied Originating Locations**

[Add](#) [Remove](#) [Filter: Enable](#)

0 Items

<input type="checkbox"/>	Originating Location	Notes
--------------------------	----------------------	-------

[Commit](#) [Cancel](#)

## 6.6 Add Session Manager

Adding the Session Manager will provide the linkage between System Manager and Session Manager. Expand the **Session Manager** menu on the left and select **Session Manager Administration**. Then click **Add** (not shown), and fill in the fields as described below and shown in the following screen:

Under *General*:

- **SIP Entity Name:** Select the name of the SIP Entity added for Session Manager
- **Description:** Descriptive comment (optional)
- **Management Access Point Host Name/IP:** Enter the IP address of the Session Manager management interface.

Under *Security Module*:

- **Network Mask:** Enter the network mask corresponding to the IP address of Session Manager
- **Default Gateway:** Enter the IP address of the default gateway for Session Manager

Use default values for the remaining fields. Click **Commit** to add this Session Manager.

The screenshot displays the 'Edit Session Manager' configuration interface in Avaya Aura System Manager 8.1. The left sidebar shows the navigation menu with 'Session Manager Administration' selected. The main content area is divided into two tabs: 'General' and 'Security Module'. The 'General' tab is active, showing the following fields:

- SIP Entity Name:** devcon-sm
- Description:** (empty)
- \*Management Access Point Host Name/IP:** 10.64.102.116
- \*Direct Routing to Endpoints:** Enable
- Data Center:** None
- Avaya Aura Device Services Server Pairing:** None
- Maintenance Mode:** ☐

The 'Security Module' tab is also visible, showing the following fields:

- SIP Entity IP Address:** 10.64.102.117
- \*Network Mask:** 255.255.255.0
- \*Default Gateway:** 10.64.102.1
- \*Call Control PHB:** 46
- \*SIP Firewall Configuration:** SM 6.3.8.0

The following screen shows the **Monitoring** section, which determines how frequently Session Manager sends SIP Options messages to Scout VoIP Console. Use default values for the remaining fields. Click **Commit** to add this Session Manager. In the following configuration, Session Manager sends a SIP Options message every 900 secs. If there is no response, Session Manager will send a SIP Options message every 120 secs.

**Monitoring** ▼

Enable SIP Monitoring ☒

\*Proactive cycle time (secs)

900

\*Reactive cycle time (secs)

120

\*Number of Tries

1

\*Number of Successes

1

Enable CRLF Keep Alive Monitoring ☐

\*CRLF Ping Interval (secs)

0

## 7 Configure Avtec Scout VoIP Console


This section covers the configuration of Scout VoIP Console using the **Scout Manager** application. This section assumes that the Scout VoIP Console software has already been installed successfully. In the **Scout Manager** application, the following procedures are performed:

- Launch Scout Manager
- Add Local Domain
- Add Endpoints
- Add Access Control List (ACLs) – Trusted Endpoints
- Add Routes


### 7.1 Launch Scout Manager



Log into the **Scout Manager** application by clicking on the appropriate icon. The following screen is displayed. Log in with the appropriate credentials.


A login dialog box for the Avtec Scout Manager application. At the top center is the Avtec logo, which consists of a red square with a white stylized 'A' and the word 'AVTEC' in white on a dark blue background. Below the logo, there are two input fields. The first is labeled 'Username:' and the second is labeled 'Password:'. Both fields are empty. At the bottom of the dialog, there are two buttons: 'OK' and 'Close'.

Once logged in, the **Scout Manager** screen appears as shown below. Click on the **Lock** icon to allow configuration.



## 7.2 Add Local Domain

Create an Avtec SIP Proxy domain. Navigate to **SIP Trunk** → **Local Domains** and click the **Add** button (not shown). The **Domains Served by this Avtec SIP Proxy Instance** page is displayed as shown below. For the **Domain Name**, enter the IP address of the Scout VoIP Console. Enable the **Allow Dynamic Users** option and specify a **Dynamic User Password** to be used by SIP extensions during registration with the Scout SIP Proxy. Click the **Add** button.



## 7.3 Add Endpoints

Endpoints are created under VPGate configuration. One endpoint was created per SIP line. Navigate to **VPGate → Endpoints** and click the **Add** button in the Endpoint Summary page (not shown). The **Endpoint Configuration** page is displayed as shown below.

Under **Endpoint Configuration**:

- **Endpoint Name:** Specify a descriptive name (e.g., *Line1*).
- **Service State:** Set to *AVAILABLE*.


Under **Endpoint Connection**:

- **Endpoint Audio:** Set to *VoIP*.

Under **VoIP Audio Settings**:


- **Receive Audio Mode:** Set to *FULL DUPLEX*.

Use the default settings for the remaining fields. Click the **Add** button.






The endpoint previously added is now displayed in the **Endpoint Summary** page shown below. Click on the endpoint that was previously added (i.e., *Line1*) to open the configuration again.




The **Endpoint Configuration** page is displayed. Scroll to the bottom of the page to the **Drivers** section as shown below. Select *SIP* from the drop-down field and click **Add driver**.




The **SIP** page is displayed as shown below. Under **Primary Identity**, configure the following fields:


- **Display Name:** Specify a descriptive name (e.g., *Line1*).
- **Username:** Specify a descriptive name (e.g., *78800*).
- **SIP Server Address/Domain name:** Specify the IP address of Scout VoIP Console, which is also the local domain.
- **SIP Server Port:** Specify port *5060*.
- **Authentication Username:** Specify the SIP extension (e.g., *78800*).
- **Authentication Password:** Specify the password used for SIP registration as configured in **Section 7.2**.
- **Register with SIP Server:** Enable this option.



Scroll down to the **Codec Configuration** section and specify the codecs to be supported. In this example, G.711, G.729, and G.726 were enabled.



Lastly, scroll down to the **Advanced Configuration** section and **Enable Inactive Hold**. This is required for attended/supervised transfers to work properly. Click the **Add** button.




## 7.4 Add Access Control List (ACLs) – Trusted Endpoint

Configure an access control list (ACL) for SIP trunking. An ACL is added to trust calls from Session Manager. Navigate to **SIP Trunk** → **ACLs** and click the **Add** button as shown below (not shown).

The **Access Control List (ACL) – Trusted Endpoints** page is displayed as shown below. Configure the following parameters as follows:

- **Name:** Provide a descriptive name (e.g., *AvayaSIPTrunk*).
- **Host IP Address:** Specify the SIP signaling interface of Session Manager (i.e., *10.64.102.117*).
- **Host Port:** Enter '0' to trust traffic coming from any port.
- **Transport Protocol:** Specify the transport protocol (i.e., *UDP*).

Click the **Add** button.




## 7.5 Add Routes

Configure routes for calls to Session Manager destined for local H.323 and SIP stations, voicemail system, and PSTN, as necessary. Navigate to **SIP Trunk** → **Routes** and click the **Add** button (not shown). The **Routes** page is displayed. For example, to route calls to local H.323 stations, the following parameters were configured:

- **Descriptive Name:** Provide a descriptive route name.
- **URI Match Expression:** Enter an expression that identifies a route for calls with a 5-digit dial number starting with '77', such as `^sip:(77\d{3})@`
- **Destination Expression:** Enter the destination URI that routes calls to Session Manager. In this case, the expression used was `sip:$1@10.64.102.117`.

Click the **Add** button.



Add additional Routes as necessary. For the compliance test, the following Routes were configured.

The screenshot displays the Avtec SIP Proxy Configuration window within the Scout Manager application. The main panel shows the 'Route Summary' for the 'SIP Trunk' configuration. The table lists the following routes:

Name	Match URI	Method	Event	Destination URI
Avaya_Messaging	^sip:(785\d{2})@			sip:\$1@10.64.102.117
Avaya_H323	^sip:(77\d{3})@			sip:\$1@10.64.102.117
Avaya_SIP	^sip:(780\d{2})@			sip:\$1@10.64.102.117
PSTN	^sip:(91908\d{7})@			sip:\$1@10.64.102.117

The right sidebar shows the properties for the 'SIP Trunk' configuration, including the name 'SIP Trunk', description, device name 'DESKTOP-N', network address '192.168.100', protocol 'http', and port '80'.



## 8 Verification Steps

This section provides the tests that can be performed to verify proper configuration of the Avtec Scout VoIP Console with Avaya Aura® Communication Manager and Avaya Aura® Session Manager. The following steps can be used to verify installations in the field.

1. Launch the Avtec Scout VoIP Console. The Scout VoIP Console will be displayed as shown below. If the SIP trunk is down, the line buttons will display *Unavailable*. The line buttons shown below indicate that the SIP trunk is in-service.



- Verify that the SIP trunk between Session Manager and Scout VoIP Console is up by navigating to **Home → Elements → Session Manager → System Status → SIP Entity Monitoring** on System Manager. Below is the status of the SIP trunk to Scout VoIP Console.

**AVAYA**  
Aura® System Manager 8.1

Users ▾ Elements ▾ Services ▾ | Widgets ▾ Shortcuts ▾

Search 🔍 🔔 ☰ | admin

Home Session Manager

Session Manager ^

Dashboard

Session Manager Ad...

Global Settings

Communication Pro...

Network Configur... ▾

Device and Locati... ▾

Application Conf... ▾

System Status ^

SIP Entity Monit...

### SIP Entity, Entity Link Connection Status

This page displays detailed connection status for all entity links from all Session Manager instances to a single SIP entity.

Status Details for the selected Session Manager:

#### All Entity Links to SIP Entity: Avtec Scout

Summary View

1 Item 🔍 Filter: Enable

	Session Manager Name	IP Address Family	SIP Entity Resolved IP	Port	Proto.	Deny	Conn. Status	Reason Code	Link Status
<input type="radio"/>	<a href="#">devcon-sm</a>	IPv4	192.168.100.251	5060	UDP	FALSE	UP	200 OK	UP

Select : None

- Verify that the SIP trunk between Communication Manager and Session Manager is in-service using the **status trunk** command on Communication Manager.
- Place an incoming call to Scout VoIP Console and answer the call. Verify two-way audio is provided.
- Place an outgoing call from Scout VoIP Console to an Avaya local station or PSTN and answer the call. Verify two-way audio is provided.

## 9 Conclusion

These Application Notes describe the configuration steps required to integrate Avtec Scout VoIP Console with Avaya Aura® Communication Manager and Avaya Aura® Session Manager. A SIP trunk was established between Avtec Scout VoIP Console and Avaya Aura® Session Manager and basic telephony features were verified. All feature and serviceability test cases were completed successfully with observations noted in **Section 2.2**.

## 10 References

This section references the product documentation relevant to these Application Notes.

- [1] *Administering Avaya Aura® Communication Manager*, Release 8.1.x, Issue 2, July 2019, available at <http://support.avaya.com>.
- [2] *Administering Avaya Aura® Session Manager*, Release 8.1, Issue 1, June 2019, available at <http://support.avaya.com>.

---

**©2019 Avaya Inc. All Rights Reserved.**

Avaya and the Avaya Logo are trademarks of Avaya Inc. All trademarks identified by ® and ™ are registered trademarks or trademarks, respectively, of Avaya Inc. All other trademarks are the property of their respective owners. The information provided in these Application Notes is subject to change without notice. The configurations, technical data, and recommendations provided in these Application Notes are believed to be accurate and dependable but are presented without express or implied warranty. Users are responsible for their application of any products specified in these Application Notes.

Please e-mail any questions or comments pertaining to these Application Notes along with the full title name and filename, located in the lower right corner, directly to the Avaya DevConnect Program at [devconnect@avaya.com](mailto:devconnect@avaya.com).